


### Document: #HT000014

### **Document Title: Remove PLC**


### Product(s): T-275

### **Procedure:**


Turn Main Power OFF.




Remove Side Panel, and locate PLC.




Locate the Blue Tabs on the bottom of the PLC. With a small screwdriver carefully pull them down to unlock the PLC and Analog Card from the Din Rail.




Carefully pull the bottom of the PLC out first, and lift the PLC out.



Release the clips holding the wire connectors to the PLC, and carefully pull the connector out, noticing the connectors are labeled so they can be re-assembled properly.




If there are no labels on the connectors, mark the locations as follows:



Save this for when you reinstall your PLC. Note: make sure PLC is in RUN mode.

Pull out the Blue Tabs between the PLC and Analog cards, and separate the PLC from the Analog Card. Remove or disconnect all remaining cables, and lift the PLC out of the Bagger.



Completely fill out the following form, and include it when shipping PLC back for reprogramming.



### **PLC Return Form**

In order to ensure quick and accurate repair of your PLC, please provide the following information:

Company Name:		
Address:		
Contact Name:		
City:	State:	Zip:
Phone: ( )	Email:	
Machine Model:	S/N:	
TS Version:	PLC Version:	

Reason for Return:	Comments:
Repair	
Reprogram	
□ New Battery	
□ Other	

Please check all options currently on the Bagger:			
□ Accumulating Funnel	🗆 Insert Funnel	Counting Funnel	
🗆 Trim Seal	🗆 UF-5000	🗆 Load Shelf	
Part Diverter	🗆 Flat Seal	🗆 US-5000	
🗆 Printer	Palm Buttons	🗆 Twin Seal	
🗆 во-20	□ BO-30	🗆 Light Curtain	
Compartment Seal	🗆 E-Stop	🗆 Barcode Reader	
Medical Validation	□ Other		

When the form is completed, please send the PLC and form to:

Advanced Poly Packaging

1360 Exeter Road – Shipping/Receiving

Akron, OH 44306

Attn: Gary Baker, Service Department