**Document: #HT000005**

Document Title: Clear RAM

Product(s): Ti-1000 TEC Printer

Procedure:

With power **"OFF"**, hold down **"FEED"** and **"PAUSE"** buttons on the control panel.

While holding buttons, turn Power **"ON"**.

Press **"FEED"** button 4 times.

Press **"PAUSE"** button 1 time.

Press **"FEED"** button 2 times.

Press **"PAUSE"** button 1 time.

Screen should display **"COMPLETE"**.

Turn Power **"OFF"**, wait 1 minute, turn Power back **"ON"**.