

# How To

## Service Documents from APPI

Document: #HT000074

Document Title: Restart UF-5000 After Error Condition

Product(s): UF-5000

### Procedure:


If any "ERROR" stops the UF-5000 attached to an Accu-Count System, such as:

- Mis-Print / Printer Error / Anti-Jam / Feed Error / Out of Bags / Ribbon Error

Follow this procedure to restart the system back to automatic operation:

After an error puts the system into "Stop", go into the UF-5000 Conveyor screen, and put the 4 top buttons in the following conditions:

- Start (Green)
- Manl (Green)
- Setup (Yellow)
- UF5K (Green)





# How To

## Service Documents from APPI

1. Push the **“Manual Cycle”** button on the far right to cycle the Bagger once.
2. Push the **“Conv Index”** button to cycle the conveyor once.
3. Now put **“Setup”** into **“Run”** and **“ManI”** to **“Auto”**.

The system will now begin to run back in Full Automatic Operation. Repeat these steps after any error that stops the system.