

How To

Service Documents from APPI


Document: #HT000221

Document Title: How to Replace Takeup and Supply Spindle

Product(s): TI-1000ZT

Procedure:

Remove Ribbon From the Take Up and Supply Spindles




Remove Side Cover (4 Screws, 2 Top, 2 Bottom)



For Take up spindle, remove belt and pulley first

Remove screws from Spindle being replaced



Remove Old Spindle and replace with New Spindle
Line up slots and Screw holes

