


Document: #HT000187

**Document Title: How to PLC removal** 

Product(s): T-300 / T-375

Battery Part # TP-214111

**Procedure:** 









Power Off

If your Bagger has a Main Power Lockout Switch, turn it counter clockwise to OFF.

Remove the two Button Head Screws holding the side panel on and remove side panel.








Close Up View






Locate the two Blue Tabs on the bottom of the PLC. With a small screwdriver carefully pull them down to unlock the PLC and Analog Card from the Din Rail.





Carefully pull the bottom outfirst.





Lift PLC out



In-between the PLC and the Analog Card on the bottom, pull the Blue Tab out.



Pull the Blue Tab out on the top.






Carefully separate the PLC from the Analog Card




Carefully pull back the two clips holding the wire connector.




Page 6 of 9



Carefully pull connector out. Notice the Connectors have a label on them. X means input, and Y means output. They are labeled so they can be put back together properly. If there are no Labels be sure to mark connectors for their locations on PLC.



Un-plug the Black Com. Connector.








On the bottom of the PLC, disconnect the Green Connector, and the White Connector.





PLEASE COMPLETELY FILL OUT FORM ON NEXT PAGE AND INCLUDE IT WITH PLC



## **PLC Return Form**

In order to ensure quick and accurate repair of your PLC, please provide the following information:

Company Name:				
Address:				
Contact Name:		Distributor (If Applicable):		
City:		State:	Zip:	
Phone: ( )		Email:		
PO Number:		Preferred Shipping Method:		
Machine Model:		S/N:		
TS Version:		PLC Version:		
TO VOICION.		1 Lo Volcielli.		
Reason for Return:		Comments:		
D Repair				
D. S.				
D Reprogram				
D New Battery				
D Other				
Please check all options currently on the Bagger:				
☐ Accumulating Funnel	☐ Insert Fur	nnel	☐Counting Funnel	
☐ Trim Seal	☐ UF-5000		☐ Load Shelf	
☐ Part Diverter	☐ Flat Seal		☐ US-5000	
☐ Printer	☐ Palm Butt	ons	☐ Twin Seal	
☐ BO-20	☐ BO-30		☐ Light Curtain	
☐ Compartment Seal	☐ E-Stop		☐ Barcode Re	eader
☐ Medical Validation	☐ Other			

When the form is completed, please send the PLC and form to:

Advanced Poly Packaging 220 Ascot Parkway - Shipping/Receiving Akron, OH 44223

----

Attn: Gary Baker, Service Department