



# How To

## Service Documents from APPI


**Document: #HT000184**

**Document Title: Adjust Driven Roller Speed**

**Product(s): T-375**

**Procedure:**

Go to Main Menu.



Select Technical Assistance. Enter Code **1001** on Keypad., and press Enter.




# How To

## Service Documents from APPI



Select **APPI**. Enter Code **9001** on Keypad., and press **Enter**.



Select the **Main Drive** button, and select **Driven Roller**.




# How To

## Service Documents from APPI




Return to the **Main Menu** and on to the **Technical Assistance** screen and select **Factory Settings**, selecting **Perf Registration**.





# How To

## Service Documents from APPI



Select the **Ribbon Speed** button.

Enter **150** on the Keypad, and press **Enter**.

Press the red **STOP** button. The button will toggle to **RUN** (Green)

Leave the yellow **MANL** button in **Manual Mode**.

Press the yellow **SETUP** button to toggle to **RUN** (Green).

Load a stored label in the printer

Press **MC** button to cycle the T-375 to test print a label

Test print several labels

Adjust **Ribbon Speed** and/or **Print Head** for good quality print

See Help Doc 19 T-375 Print Head Adjustment.

*NOTE: A Ribbon Speed of 150 will normally result in a good printing of a label with a print speed of 5 or 6. However, adjustment of the Ribbon Speed may be required.*