

Document: #HT000054

Document Title: Valve Station Assignments

Product(s): T-1000

Procedure:

The T-1000 S14 has Valve Station Assignments. Valves 1 thru 4 are Default in the PLC Program. If there are additional Options on the T-1000 S14, you will need to assign it a Valve Station.

If you are sending in a PLC for programing, it is recommended that you write down or take a picture of the Valve Assignments. You may want to take pictures of all your bag settings also. This will help you get your machine up and running more quickly.

N V I I	STOP MAI	SETUP		
	Operation	Bagger Settings	Options	
	Counters	Job Search	Job Save	
	Graph Menu	Auxiliary Options	Log Menu	
	Printer Setup	Machine Info	Technical Assistance	\triangleleft

From the "Main Menu" press "Technical Assist".

How To Service Documents from APPI



Enter the Pass Code "1001", then press ENT.



Press "Option PassCode"



Press "Station Set-Up"





This screen shows the Station Assignments for the Options that are on the Bagger. This is what you want to document. Notice that Flat Seal has been assigned to Valve #6.



To Assign a Valve Station:

Select the option and press the **#**.

STOP MANL SETUP MANUAL Solenoid Activation					
Load Shelf	# 5	BO Forward	# 7		
Flat Seal	# 6	B0 Up∕⊅own	# 8		
Trim Seal 🛌	, # 0	Custom Opt1	# 0		
Accumu 1 _r	# 0	Vib. Tapper	# 0		
Diverter	# 0	BagDeflator	# 9		
		Reset	Return		

Enter the "Valve Station" the press "ENT".

